



Herbert

Owner's Manual

Diezel UK
Leader Campbell Ltd.
120 Holloway Road
London
N7 8JE.

Table of Contents

Chapter One: Safety and Warranty

- 1.1 Safety Warnings
- 1.2 Warranty Information

Chapter Two: Using Your Herbert

- 2.1 Mains Connections, Power and Standby
 - 2.1.1 Mains/connect to power outlet
 - 2.1.2 Power up, Warm up, Standby off
 - 2.1.3 Power tube caution
 - 2.1.4 Operating Temperature
 - 2.1.5 Power Tube Information

Chapter Three: Peripheral Connections

- 3.1 Front Panel Connections
 - 3.1.1 Signal In
 - 3.1.2 Connection Information
 - 3.1.3 Cable Selection
- 3.2 Rear Panel Connections
 - 3.2.1 Send/Return Loop
 - 3.2.2 Parallel and Serial Return
 - 3.2.3 Switch-able Loop as additional Volume Control
 - 3.2.4 Switch-able Loop for external Pre-Amp
 - 3.2.5 Switch-able Loop as switch for parallel Loop
 - 3.2.6 Tuner Out
 - 3.2.7 Compensated Out
 - 3.2.8 Speaker Connections
 - 3.2.9 Reasons for Dynamic Losses in the Effects Loop
- 3.3 MIDI Connections
 - 3.3.1 MIDI In
 - 3.3.2 MIDI Thru

Chapter Four: The Three Pre-Amplifiers

- 4.1 Pre-Amplifier Duties
 - 4.1.1 Channel One
 - 4.1.2 Channel Two
 - 4.1.3 Channel Three
- 4.2 Pre-Amplifier Tubes
- 4.3 Noise and Micro-phonics

Chapter Five: Power Amplifier

5.1 Tone and Volume of the Power Amplifier

5.1.1 Master Volume

5.1.2 Presence

5.1.3 Deep

5.2 Power Amplifier Tubes

5.2.1 Function

5.2.2 Selection

5.2.3 Life Span

Chapter Six: Functions and Switches

6.1 Programming Herbert

6.2 Manual Channel Selection

6.3 Mid Cut on/off

6.4 Loop on/off

6.5 Mute on/off

6.6 Master 2

6.7 Store

Chapter Seven: Midi

7.1 MIDI

7.2 MIDI In

7.3 MIDI Thru

7.4 MIDI Communication

7.4.1 Omni Mode

7.4.2 Single Channel Mode – automatic Channel Recognition

7.4.3 Single Channel Mode – manual Channel selection

7.5 Program Information

7.6 Phantom Power

Chapter Eight: Remote Switch

Chapter Nine: Maintenance and Cleaning

9.1 Cleaning

9.2 Care

9.3 Tube Change

Chapter One: Safety and Warranty

1.1 Safety Warnings

We would like to stress the importance of the following points, for reasons of your personal safety, product longevity and product liability.

- Do not use the amplifier in or near wet locations
- Do not store the amplifier in damp or wet locations
- Do not operate the Amplifier on voltages other than those designated on the rear panel of the amplifier.
- Do not open the panels of the amplifier. No user serviceable parts inside.

Your Herbert operates on very high internal voltages, which may still be present after the Amplifier has been turned off and disconnected for a while.

- Do not use the Amplifier for anything other than its design purpose: To Amplify Electric Guitar Signals!
- Do not use fuses other than those intended and specified for the amplifier
- Do not use 2-conductor extension cords or anything other than 3-pole grounded outlets for this Appliance. Your life may depend on it!

Please observe the following points when transporting your Herbert:

Herbert is a *Tube Powered Amplifier*; therefore it is sensitive to *shock*, especially after playing the amplifier for a while. Please store and transport your amplifier gently, and try and avoid temperature extremes in storage, which might cause condensation resulting in moisture on internal components. Usually a 60 Minute acclimatization period is sufficient to ensure safe operation.

The Amplifier should be stored in a controlled environment, and it should be transported in a suitable flight case. Make sure the Amplifier gets transported in its normal operating position, not upside down or on its side.

The Herbert's Design incorporates a very potent power amplifier. It is configured to deliver satisfying guitar tone at most volume levels, from a small bedroom to a large arena. In its normal operational volume level (75-80dB) it will provide beautiful tones with very little coloration. For reasons of your own personal health, please do not run the amplifier above these levels for extended periods of time without wearing hearing protection. Hearing Loss is a long-term problem, and is normally not curable.

1.2 Warranty

Diezel GmbH of Munich, Germany offers a 1-year transferable warranty on the product "Herbert". Diezel GmbH of Munich offers a lifetime non-transferable warranty to the ORIGINAL purchaser of the product: "Herbert". The product must be registered and a dated sales receipt must accompany the registration.

Excluded from this warranty are all vacuum tubes, and any abuse of the amplifier.

Also excluded from this warranty are damages due to not following the Safety Warnings in 1.1 above and 9.2 below. LEADER CAMPBELL Ltd is the local executor of this warranty. Customer is responsible for shipping charges to LEADER CAMPBELL Ltd in London, unless other arrangements are made in advance.

Chapter Two: Using Your Herbert

2.1 Mains Connections, Power and Standby

2.1.1 Mains/Connection to Power Outlet

Please make sure that both switches (Power and Standby) are in the off position before connecting to the Mains circuit. Verify line voltage before connecting the power cord. Never start Herbert without speakers being connected to the proper terminals. (See 3.2.8)

2.1.2 Power up, Warm up, Standby off

First turn the Power switch to on (facing up). The indicator will light up. This starts the tube heating process. After about 40 seconds, the tubes have sufficiently heated for normal operation. Your Herbert is now ready for operation and the standby switch can be turned to “run” (also facing up). Premature activation of the standby switch will lead to unnecessary tube stress and subsequent reduction of the power tube’s life span.

2.1.3 Power Tube Caution

Tubes are electronic components that only function with vacuum intact and under very high operating temperatures. Each tube has one or more heating filaments, much like a light bulb. These filaments heat up the Anode of the tube. If you switch the standby switch before these Anodes have reached their operating temperature then the Anode surfaces are not heated evenly yet; the “operating temperature” of the tube is not reached yet. This causes undue stress on the tubes and their related components inside the amp. One should therefore always give the amp it’s much needed warm-up time, even if musical inspiration hits with full force.

2.1.4 Operating Temperature

It will take a little more time after warm-up until everything inside the amp is working in sync and to it’s fullest potential. A trained ear will notice a slightly warmer tone and better complexity in tone after playing the amp for a short while. It’s like warming up before running a marathon. Get it?

2.1.5 Power Tube Life

The power tubes of your amplifier are subject to a certain aging process. Once one of the tubes shows signs of aging, unreliability or unusual noise, then we suggest that you replace all power tubes. Matched tube sets wear relatively even, or so our experience suggests. This means if one goes, the others are not far from meeting the same fate. The aging process manifests itself by a depletion of a thin layer of Wolfram on the Anodes. This can take anywhere from 6 month to 3 years, depending on the amount of use of the amplifier. The amount of wear is determined by the amount of performance that is asked from the tube.

Chapter Three: Peripheral Connections

3.1 Front Panel Connections

3.1.1 The input jack (“IN”) receives your Electric Guitar signal by means of a shielded guitar cord with 1/4” mono style plug. Your guitar cord is an important part of your signal chain and its quality and construction type clearly affect the overall tone of your rig. Try and buy the best quality guitar cord that you can or want to afford. Call us if you have doubts and need recommendations. This is where the smart “weak link” comment comes in. Get it?

3.1.2 Cable ABC

Some cords and cables sound very neutral; others color the sound spectrum and/or attenuate high frequencies due to capacitance inside the wire and shield. What are we talking about? OK. A capacitor is used in electronic crossovers, amongst other things, to divide low and high frequencies. Capacitance in a cable therefore cuts your guitar’s high end to a certain degree. Generally, the longer of a cord you use, the more of the cords inherent characteristics will be audible.

3.1.3 Cable Selection

In certain instances it is desirable to match a guitar cord to a specific instrument.

One can use the otherwise undesirable qualities of a cord to one's advantage, if one has the time and patience to experiment with different cords and guitars. You should do this when playing with a band or when you are recording. Sometimes it is difficult to tell a component's true advantages until it is used in the right context. A guitar that has very piercing highs could theoretically be tamed down somewhat by the use of a long guitar cord that offers some high-end attenuation. The loops of your Diezel Herbert send signals at higher levels and impedances, which makes this section of wiring less sensitive. You should still use reliable and good quality wiring for all loops and inserts.

3.2 Rear Panel Connections

3.2.1 Send/Return Loop

The System consists of 3 separate Loops. It allows creation of effects path in either serial, parallel, or switched configurations. The individual channel volume controls determine the signal strength at the send jacks. The range is - ... to +10dB. The output impedance is 4.7 k Ω if you want to use the loops, then connect the "Send" to the input of the Effects unit. Be sure and adjust the input level of the effects unit to the amplifiers level. Most effects units have an led bar or other level control devices. The Output of the effects unit must be connected to one of the return jacks, parallel, switched, or serial. If you use the parallel return, then the signal can be mixed to the original signal via the rear panel mounted "Volume" control.

3.2.2 Parallel or Serial

Which is better for you? Read on.

There are 2 ways to handle effects signals. If you use the serial return, then the signal path of your Herbert is interrupted, the signal is sent to the processor, gets more or less processed, then sent back to the serial return into the power amp.

Digital effects units often digitize this signal, then process it, then convert it back to analog, then send it to the amp. This is called ADA conversion. It is necessary for digital effects units to do this to your guitar signal, so that it becomes a digital code, which the processor can read and understand. Your tubes, however, need an old fashioned analog signal, so the processor needs to convert the signal back to analog before it goes back to the amp. Generally, even in highest quality effects processors, this causes a change in the original signal, typically a loss of tonality and warmth, also noticeable as a "harder" sound.

When you use the serial loop for an effects unit like this, then your signal will have been ADA converted at least once. Tone junkies and vintage freaks alike will more than likely have hives developing by now. But, as always, there is a better way. Using the Parallel loop and the mix (labeled "Volume") control on the back determines how much effect signal is being added to the original signal, which now still flows through the amplifier. There is always an analog connection between the send and return jacks: a parallel loop!

Important: You must set the mix control on the effects unit to 100% wet when using the parallel loop. Otherwise there will be nasty phasing problems resulting in unsatisfactory tone. The signal portion that is unaffected by the mix control in the effects unit would reach the amplifier at a different time due to the cabling, and cause phasing cancellations.

3.2.3 Switch-able Loop as additional Volume Control

Those of you who can live without processors in the parallel loop can use this loop for a second master volume for each channel. To do this, just loop a short 1/4" cable from the switch-able send to parallel loop return. Now you can choose a second master volume by turning the mix control past 1:00 PM to full open, and push the ' Loop" button to activate your second master volume. Now, with the loop activated, the mix control can act as another way to control volume.

3.2.4 Switch-able Loop for external pre-amp

One might extend one's tonal variety by hooking up an external guitar pre-amp to the switch-able return jack. Now the external preamp, once selected via the "Loop" function, can feed the Herbert's power amp.

3.2.5 Switch-able Parallel Loop

To route your effects signal parallel to the original signal, connect the switch-able send to the input of your effects unit and go from the output of your effects unit to the parallel return. Now you can switch the send to the effects unit on and off via midi, with the effects signal decaying naturally when the loop is turned off.

3.2.6 Tuner Out

You guessed it – it's for a guitar tuner. Stays lit while mute is activated. So you can tune without annoying your band members, or the audience. Elegant, no?

3.2.7 Compensated Out

A frequency corrected signal will leave this jack if you connect it to a mixer or recording device. Use it to quietly compose or send an auxiliary signal to a console etc. For quiet sessions, just turn the master volumes to "0". Recording a loudspeaker through a microphone is the preferred choice of recording engineers.

The compensated out was designed as an alternative for those of you that don't have a studio at your fingertips.

3.2.8 Speaker Connections

Herbert has 5 speaker jacks: 1 for a 16-Ohm load, 2 for 2 16-Ohm loads or 1 8-Ohm load, and 2 for 2 8-Ohm loads or 1 4-Ohm load. Confusing? Oh, yes!

Just do what it says on the jacks, and you'll be fine.

3.2.9 Top 5 Reasons for dynamic losses in the effects loop

Many different factors can be responsible for loss of dynamics, aside from those mentioned in 3.2.2 (ADA conversion). A vital point that often leads to frustration is a maladjusted output level of an effects unit. If the output level is too high, then unwanted distortion is caused in the power amp. If it is too low, then the rig will not sound punchy and might get lost easily in the band sound. When used in the serial loop, the output of the effects unit determines the ultimate drive signal strength of the power amp. The output level should be matched to give the best possible sound with all 3 channels without over driving the power amp section.

Headroom adjustments of 10% are usually sufficient.

3.3 MIDI Connections

3.3.1 MIDI In

Midi in receives "program change" orders from commonly available midi pedals and control systems. The Herbert is able to supply phantom power to your midi pedal via a 7-prong DIN midi cable. This can help unclutter your stage system and rids the artist of these pesky power supplies.

Pin 1 and 6 is ground (-)

Pin 3 and 7 is hot (+)

The voltage is 9-12V AC or DC, which is acceptable for 98% of all midi pedals.

Maximum power usage of the pedal cannot exceed 800mA (0.8A)

Please observe proper polarity to avoid damage to the MIDI pedal.

3.3.2 MIDI Thru

This jack routes the midi signal to other midi partners. MIDI data not addressed to the Herbert gets looped through this jack. See chapter 7 for MIDI programming instructions

Chapter Four: Three Pre-Amplifiers

4.1 Pre-Amplifiers and their Functions

The Diezel Herbert comes equipped with 3 different and totally independent preamps. This allows the artist to play every conceivable musical style without having to make major changes to his or her amplifier. The preamps are voiced to deliver the 3 most wanted guitar tone flavors: 1-Clean, 2-Crunch/Heavy 3- Lead.

This concept delivers 3 stellar guitar sounds with excellent playability, warm dynamics and razor sharp equalization possibilities. The tone controls work in an unusually wide range, so a little adjustment goes a long way. As with so many other things - less is often more. We suggest you start exploring the channels with all controls set to 12:00 o'clock, and the master volume just slightly cracked open.

(To avoid hearing damage)

4.1.1 Channel One (Clean Tone)

Clean Tone is a very sensitive subject, because there are so many different ideas on how a clean amp should sound like. Clean tonal textures require much higher dynamic range than distorted sounds. From hard and percussive sounds to soft and warm blossoming tones. Herbert was designed to offer as many of the clean variety as possible. Your choice of guitars and pickups will have a large part in this equation.

4.1.2 Channel Two (Crunch)

This channel's main objective is to cover soft and heavy overdrive and distortion sounds. It features a voicing switch, with -/+ settings. With the (-) setting selected, blues and classic rock sounds can easily be realized. The (+) setting kicks everything up a few notches and offers crunch with a good bite, allowing you to dial in punchy heavy rhythm and searing solo tones.

4.1.3 Channel Three (Lead)

This channel is voiced for highly articulate single note lines or for very heavy and massive rhythm guitar. Due to its slight midrange accent and very high gain structure, it possesses good punch and will, with ease and authority, rule any stage or studio. The "less is often more" rule applies here also.

4.1.4 Mid Cut

The section Mid Cut incorporates controls for Intensity and Level. Designed for friends of Heavy or Nu-Metal type musical styles, the Intensity control attenuates low midrange at approximately 400Hz. To compensate for the inevitable volume loss when activating this feature, one can bring the volume level back up with the Level Control.

This Mid Cut function is MIDI assignable and can therefore be assigned to any or all of the three channels. If you don't want to use the Mid Cut function, then it can be used as an additional programmable volume control with the Intensity control set to 0 or off. This gives your Herbert 8 programmable volume options!

4.2 Pre-amp Tubes

The pre-amps are equipped with 12AX7 tubes in all positions, except the phase inverter, which is a 12AT7. The pre-amp tubes are not used to make big power, but merely as pre-amplifiers. Therefore their life expectancy is much higher than that of the power amplifier tubes.

This is not to undermine their utter importance in overall sound and response of the amplifier. Also, many nuisance defects like crackling noises and low dynamics are directly related to defective pre-amp tubes. Like all other tubes, 12AX7 tubes come in many different gain stages, and offer a wide variety of tonal behavior. Our choice for production was made to ensure a wide variety of tones, with low noise and, hopefully, excellent reliability.

4.3 Micro-physics and Bad Noises

The overall performance of pre-amp tubes is easily influenced by mechanical factors from the outside. This would manifest itself by a sudden feedback sound with high pitch. The input stage is especially suspect to this phenomenon. If one encounters microphonic tube behavior, then the first tube should be checked as a rule. Pre Amplifier tubes can also cause hum or other bad noises, like crackling or ticking.

Chapter Five: Power Amplifier

5.1 Tone and Volume of the Power Amplifier

5.1.1 Master Volume

As the name suggests, this controls the overall, global volume of the amplifier.

For your enjoyment, there is also a second programmable master volume control, which allows volume adjustments via remote control while you are playing. Both controls are laid out so that even a low-performance effects unit can be used and amplified in the loops.

5.1.2 Presence

This knob controls frequencies over 3KHz. Treble is produced and dispersed in a very small beam from the speaker, so be sure to position yourself in the projection area of the speaker when making adjustments.

5.1.3 Deep

The Deep control is an active bass control, contrary to conventional bass controls. It controls the frequencies around 120Hz without influencing the overall dynamic range of the power amplifier.

Diezel Co. is not responsible for disintegrating speaker cabinets.

5.2 Power Amplifier Tubes

5.2.1 Function

As the name suggests, the power amp section is the part of the amplifier that produces output power, measured in watts. Preamp signals are sent to the power amp(s), which amplifies this signal to a level that is acceptable for loudspeakers.

Guitar amplifiers utilize several different types of power amps, which differ in output power and tone. We chose the tube type power amplifier for its tried-and true performance and familiar tonal behavior.

5.2.2 Selection

Diezel Co. installs the most reliable and best sounding tubes that are currently available in sufficient quantities. So it is possible that tube brand and tube type will change during production. You can fine-tune your Herbert by having different type and brands of tubes installed, however, it is imperative that the amp is biased properly. Herbert utilizes 6 power tubes, organized in 3 pairs with triple bias possibility. This allows use of 3 different pairs of power tubes, either the same or different types. Yes, this means that you can mix 6550's with EL34's, or 6L6's with KT88's etc.

Cool, no?

A quick and general overview of the most common tube types for use in the Herbert:

EL34/6CA7: Aggressive, slender low end, higher total harmonic distortion... Recommended bias setting: 30-35mA

5881/6L6: Great tube for clean sounds, good bluesy tones, also has strong bass and excellent clarity... Recommended bias setting: 25-35mA

6550: Very loud, very good dynamics, strong low end, amazingly percussive... Recommended bias: 40-60mA

KT88/KT100: Similar to 6550, but very punchy with great clarity and warmth... Expensive... Recommended bias: 35-50mA

5.2.3 Life Span

Power tubes last 1 to 3 years, depending on care, volume and frequency of use of the amplifier. If you use your amp only once a month, then the tubes will obviously last longer. Really... We have heard tubes that are over 10 years old, but it was not a good thing. Tubes age in a very slow manner, slow enough for the artist to get used to the changing tone. To keep things fresh and to keep your tube dealer in business, we recommend re-tubing, cleaning and biasing once a year if the amp is used frequently.

Chapter Six: Functions and Switches

6.1 Programming the Herbert

It is quite easy to program your Diezel Herbert and, also, easy to explain. Pushing the “Store” toggle switch twice must follow each change in the MIDI program.

After the first click, the selected blue LED lights will blink. Click on the switch again and your program is in memory. Each of the 128 programs (patches, program changes) can be changed as often as is desired.

6.2 Manual Channel Selection

The 3 channels of the Herbert can be selected manually by activating the red button above each channel strip, or can be programmed via the midi control system. If you assign the Channel one switch function to a MIDI program (for example “01”), then you can initiate this channel’s switching via your MIDI pedal. Push “01” on your MIDI pedal after programming, and the pedal will send digital information to the amplifier. The amp will read this information and decide whether or not it is supposed to respond. When properly programmed, it will then switch on channel one. OK, here it is again:

Select 01 on your MIDI pedal. Select channel one of the Herbert. Now push “Store” twice. Voila, it’s a MIDI program! Now select program change “02” on your pedal, switch the amp to channel two, hit “Store” twice, and suddenly you have a MIDI pedal controller with 2 program changes. Continue on until you run out of channels, about 1 more time.

All the other functions of the amp can be programmed in the same exact way. Remember: push “Store” twice to finalize a MIDI program procedure. Select the program on the pedal to recall the setting from the amp.

6.3 Mid Cut On/Off

The switching function “Mid Cut” is applicable to all channels. The Mid Cut is active when the corresponding LED is lit.

6.4 Loop On/Off

This function activates a device that is connected to the switch-able loop.

6.5 Mute On/Off

“Mute” silences the beast. “Tuner Out” stays active. Makes sense, no?

6.6 Master 2 On/Off

Master 2 can be used for all channels, much like the Mid Cut function.

6.7 Store

As discussed earlier, this is the universal programming button. Activating this button twice will verify an intended program procedure. In case you have pushed this button once by accident, or if you have started to program and don’t want to anymore for whatever reason, then you can push any other switch (any switch but the “Store” switch) to cancel the programming procedure. The previously established program will be preserved. On models equipped with GPS, this will call out the quickest way to a near by music store.

Chapter Seven: MIDI

7.1 MIDI

MIDI is an acronym for Musical Instruments Digital Interface and is an internationally accepted communications system between musical instruments (and processors and computers) of all kinds. We will only need to learn a small portion of this “language” to use the Herbert and its peripheral MIDI partners. We are going to learn only about “program change”.

7.2 MIDI In

MIDI In is a 7-pole DIN jack. It must be connected to the MIDI Out jack of your foot controller (or MIDI pedal), or the MIDI Out of any effects unit connected to the pedal directly.

7.3 MIDI Thru

Connect this port to the midi in of other units to continue the MIDI chain

7.4 MIDI Communication

7.4.1 Omni Mode

The Omni mode will allow reading of MIDI information on all 7 channels. It is an easy way to get into the MIDI system but it is not advisable if more MIDI partners on different channels are in the same system. Then a certain MIDI channel should be assigned to the Herbert and its program changes should be restricted to this channel (See 7.4.2). To put the amp into the Omni mode, hold the “Mute” switch down and activate the “Master 2” switch quickly and then release the mute switch. The Mid Cut, Master 2, Loop and Store LED’s will now blink to verify that the Omni mode is being accepted. This function needs to be disabled under some circumstances in order to use single mode automatic or single mode manual.

7.4.2 Single Channel Mode – Automatic Channel Recognition

Your Herbert can automatically recognize the pedal’s send/receive channel. To get your amp into the mood (or mode) for this, push and hold “Mute” and then activate any program change button on your MIDI pedal. The amp will look for a program change and recognize the channel it is being sent on. Then it will switch to this channel and stay there as soon as you let go of “Mute”.

7.4.3 Single Channel Mode – Manual Channel Selection

If you would like to have your Herbert on a certain MIDI channel, then we can accommodate you here as well. Here is how this works:

Push and hold “Mute” and then turn on the preamp channels in the order that corresponds to your midi channel preference. For example: if you want to have your Herbert to respond only to MIDI information that is being sent on channel 7, then you must hold the “Mute” button down and turn the Preamp channel one selector off, channel two selector on, channel 3 selector on. If you let go of “Mute” now, then your Herbert is set to respond to MIDI channel 7 only. Get it? The table below gives you the sequence for all 7 MIDI channels.

Ch.1 off off off

Ch.2 on off off

Ch.3 off on off

Ch.4 on on off

Ch.5 off off on

Ch.6 on off on

Ch.7 off on on

7.5 Program Information

Herbert can remember up to 128 program changes.

7.6 Phantom Power Several of the pins in the MIDI jack can supply phantom power to your MIDI pedal, as explained in chapter 3.3.1

Chapter Eight: Columbus

The optional 'Columbus' footswitch can be connected via the rear panel mounted XLR jack. The 'Columbus' will not recognize functions selected from the front panel. To reset, just unplug and plug in the 'Columbus'. To store a Channel and or other feature such as Switchable loop / Master Volume 2 or Mid cut. Choose the required Button number on the Columbus then set the amp toggles as desired and Press the 'Store' toggle twice, job done - now repeat for the next setting.

Chapter Nine: Maintenance and Cleaning

9.1 Cleaning

Never use a wet method of cleaning the amplifier, i.e. *any* amplifier. Usually it is sufficient to wipe down the outside of the amp with a slightly moist cleaning rag.

Do not use abrasive cleaning chemicals. Sometimes a vacuum cleaner can be used to remove dust and dirt from nooks and crevices. Do not remove the chassis from the housing to clean the amp. The inside of your amp carries dangerous voltages.

9.2 Care

Be gentle with this amplifier. Any mechanical shocks and wide temperature changes, moisture-rich environments and extreme conditions (dust, wind, heat, cold, moisture) can substantially shorten tube life, in some cases, even amplifier life.

Do not block the air circulation grilles in the front and in the back of the amp.

Do not push the amp right up against objects that would interfere with its normal airflow. The top of the amplifier might get warm after prolonged use, this is normal, but will melt your ice cream and definitely ruin your beer.

Never put beverages on top of the amp where they could spill and flow inside the amplifier. You'll hate it if this happens, Guaranteed!

If your Amplifier is returned and diagnosed an Alcoholic or with a general drink problem, your Warranty will be Invalid.

9.3 Tube Change

Tube changes are only to be undertaken by authorized service personnel. If power tubes with different values than the original ones are to be installed, then the amplifier must be re-biased before operation can be resumed. The amplifier uses a three circuit bias system. It is quick and easy to accomplish biasing, but involves removing the chassis and use of specialized equipment for measuring currents inside the amplifier. Only trained professionals should attempt this procedure.

Leader Campbell Ltd and Diezel Amplification GmbH wish to express their gratitude and congratulate you for your decision to purchase the Diezel Herbert Amplifier.